

More fun learning toys from LeapFrog!



Tad's First Feelings™ Book

6+ months



Leapstart™ Learning Table

6+ months



Learning Band™ Walker

9+ months



Learning Connections™ Train

9+ months

LEAP FROG baby Hug & Learn™ Animal Globe

What a wonderful way for baby to explore the world!



Parent Guide & Instructions

This guide contains important information. Please keep it for future reference.

www.leapfrog.com

How to get the most out of your Hug & Learn™ Animal Globe!

Rolling Rhythms!

Babies learn through simple hands-on exploration. The Hug and Learn™ Animal Globe has a soft texture that baby will love, and fun rhythms that reward each roll!

★ Once your child is ready to sit-up on her own, you can begin a fun game of rolling the ball back and forth! Encourage your child to roll the globe back to you as many times as she can, and reinforce how each roll adds a new verse and sound to the music that the globe plays. Later, as the song becomes more familiar, your child will begin to realize that every time she rolls the globe she can create a variety of fun music and sounds!

A World of Learning!

It's never too early for babies to begin exploring the world! The Hug and Learn™ Animal Globe plays 7 different responses when baby presses the 7 different continents!



★ Encourage your child to press all the different continents around the globe to get familiar with a range of animal names, sounds and colors/colours. Later, when your baby becomes more accustomed to the animals and their designated lands, play a “seek and find” game by asking your baby to find a specific animal by its continent and sound. This game is a great way to help acquaint your baby with the world around him!


A Different Feel!

Babies begin learning new things by grasping and touching. The Hug and Learn™ Animal Globe encourages baby to start learning about the world!

★ Let your baby explore the globe and allow her to make her own discoveries by using her hands! After a while, she will begin to expand her range and she will understand that the world is full of different places, which can be revealed with a simple touch!



INSTRUCTIONS FOR PLAY



Getting Started:

Turn on the HUG AND LEARN™ Animal Globe by pushing the ON/OFF button.

How to Play with the HUG AND LEARN™ Animal Globe

Roll the Globe!

- Press the ON/OFF button to begin.
- Roll the globe to hear a song about the world. Each roll will add another verse to the song, for a total of 5 verses.
- Each character introduces colors/colours, different places, vehicles and fun sounds.

Press the Globe!

- Press the ON/OFF button to begin.
- Press any of the 7 continent buttons to hear about animal names, animal sounds and animal colors/colours.
- The 7 world animals and continents include:
 - NORTH AMERICA—green crocodile, black bear
 - SOUTH AMERICA—green parrot, yellow snake
 - EUROPE—red fox, white mountain goat
 - ASIA—orange tiger, black and white panda bear
 - AFRICA—gray elephant, orange giraffe
 - AUSTRALIA—gray koala, yellow kangaroo
 - ANTARCTICA—black and white penguin, gray whale

Care and Maintenance:

- Keep product away from foods and beverages
- Clean with a slightly damp cloth
- Never submerge product in water
- Remove batteries from the globe for prolonged storage
- Avoid exposing the globe to extreme temperatures

Battery Information:

Batteries included are for in-store demonstration, and should be replaced to improve performance. Requires 3 AA (called LR06 in some countries) alkaline batteries.

Battery Safety:

Batteries are small objects. Batteries must be replaced by an adult.

Follow the polarity (+/-) diagram in the battery compartment.

Promptly remove dead batteries from the toy.

Dispose of used batteries properly.

Remove batteries for prolonged storage.

Only batteries of the same or equivalent type as recommended are to be used.

DO NOT incinerate used batteries.

DO NOT dispose of batteries in fire, as batteries may explode or leak.

DO NOT mix old and new batteries or types of batteries (i.e. alkaline/standard).

DO NOT use rechargeable batteries.

DO NOT recharge non-rechargeable batteries.

DO NOT short-circuit the supply terminals.

Sécurité relative aux piles

Les piles sont des objets de petite taille. Le remplacement des piles doit être effectué par un adulte.

Respectez le schéma de polarité (+/-) reproduit dans le compartiment des piles.

Enlevez rapidement les piles usagées du jouet.

Suivez les procédures adéquates pour vous débarrasser des piles usagées.

Retirez les piles en cas de non-usage prolongé.

Utilisez uniquement des piles ou accumulateurs du type recommandé ou d'un type équivalent.

NE PAS INCINÉRER les piles usagées.

NE PAS JETER les piles au feu, car elles peuvent exploser ou fuir.

NE PAS MÉLANGER piles usagées et piles neuves, ni différents types de piles (c'est-à-dire alcalines/standard).

NE PAS UTILISER de piles rechargeables.

NE PAS RECHARGER des piles non rechargeables.

NE PAS COURT-CIRCUITER les terminaux d'alimentation.

Battery Installation:

1. Requires 3 AA (called LR06 in some countries) alkaline batteries.
2. Open the battery door (located inside of the globe) with a screwdriver.
3. Install new batteries as shown in the polarity diagram (+/-) inside the battery compartment.
4. Replace battery door securely.

TROUBLESHOOTING

Symptom:	Try This:
Toy does not turn on or does not respond	<ul style="list-style-type: none"> • Make sure batteries are correctly installed • Make sure battery cover is securely attached • Remove batteries and put them back in • Clean battery contacts with rubbing alcohol • Install new batteries
Toy makes strange sounds or behaves erratically	<ul style="list-style-type: none"> • Install new batteries • Clean battery contacts with rubbing alcohol
Toy makes improper responses	<ul style="list-style-type: none"> • Install new batteries • Clean battery contacts with rubbing alcohol

U. S./Canada Consumer Service Contact:

Please visit our U.S. Consumer Support Web site at:

<http://www.leapfrog.com/support>, or our Canada Consumer Support Web site at: <http://lfcanada.custhelp.com>, 24 hours a day. You can search for frequently asked questions, review your previous questions, or submit a question to our support staff via e-mail.

U.S./Canada Office:

Telephone: (800) 701-LEAP (5327)

Hours: Monday through Saturday, 5:00 AM to 7:00 PM, Pacific time.

U.K. Consumer Service Contact:

Please visit our U.K. Consumer Support Web site at: <http://leapfroguk.custhelp.com>, 24 hours a day. You can search for frequently asked questions, or submit a question to our support staff via e-mail.

U.K. Office:

Telephone: 0800 169 5435

Eire: 00 44 1702 200244

Hours: Monday through Friday, 9:00 AM to 5:00 PM.

IMPORTANT: Please notify the LeapFrog Consumer Service department of any difficulties before returning this product for any reason. Returns must have a Return Authorization number (RA#) in order to be processed. If the service representative is unable to solve the problem, you will be given instructions on how to replace the product.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

AVERTISSEMENT : Tout changement ou modification de cette unité n'ayant pas été expressément approuvé par les parties responsables de la conformité entraîne l'annulation du droit de l'utilisateur à exploiter l'équipement.

Note: This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. Because this toy generates, uses, and can radiate radio frequency energy, there can be no guarantee that interference will not occur. If this toy does cause interference to radio or television reception (you can check this by turning the toy off and on while listening for the interference), one or more of the following measures may be useful:

- Reorient or relocate the receiving antenna
- Increase the separation between the toy and the radio or the TV
- Consult the dealer or an experienced TV-radio technician for help

Warranty Information

This LeapFrog product is warranted only to the original purchaser for a period of 3 months from the original purchase date, under normal use and service, against defective workmanship and material. This warranty is void if the product has been damaged by accident or unreasonable use, immersion in water, neglect, abuse, battery leakage or improper installation, improper service, or other causes not arising out of defects in workmanship or materials. Repair or replacement as provided under this warranty is the exclusive remedy of the purchaser. LeapFrog shall not be liable for any incidental or consequential damages for breach of any express warranty on this product. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited to the duration of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

During the warranty period, your product will either be repaired or replaced at LeapFrog's option, when returned, shipping prepaid and with proof of purchase date as instructed by a LeapFrog service representative. In the event that your product is replaced, the replacement product will be covered under the original warranty or for 30 days, whichever is longer.

Canada: In addition to the above-referenced warranty, the hardware component shall be free from defects in material and workmanship for 12 months. The above express warranty and any applicable implied warranties are limited in duration to the warranty periods described above. Some provinces do not allow limitations on how long an implied warranty lasts, or the exclusion of incidental or consequential damages, so the above limitations do not apply to you. You may also have other rights, which vary from province to province.

U.K.: In addition to the above-referenced warranty, this LeapFrog product shall be free from defects in material and workmanship for 12 months where the 3-month warranty period is not valid. The above express warranty and any applicable implied warranties are limited in duration to the warranty periods described above. Some provinces do not allow limitations on how long an implied warranty lasts, or the exclusion of incidental or consequential damages, so the above limitations do not apply to you. You may also have other rights under U.K. law, which this warranty does not limit.

LEAPFROG, the LeapFrog logo, HUG & LEARN, TAD'S FIRST FEELINGS, LEAPSTART, LEARNING BAND and LEARNING CONNECTIONS are registered trademarks or trademarks of LeapFrog Enterprises, Inc. Copyright © 2004 LeapFrog Enterprises, Inc. All Rights Reserved.

Visit our fun-filled Web site at: www.leapfrog.com

For ages 6 months and up
Convient aux enfants à partir de 6 mois