




Pretend & Learn™ Shopping Cart

① Attach Legs to Basket:

- Match the A leg to the A on the basket, and then match the B leg to the B on the basket. (The smooth side of each leg will be facing out.)
- Keep the legs flat against the rail (located on the bottom of the basket). Slide each leg onto the basket until it snaps into place. Arrows on inside of legs will be in alignment.

② Attach Legs to Wheelbase:

- Place wheelbase on floor as shown.
- Match A and B on the legs to A and B on the wheelbase, and press down to snap the legs into place. Snap the front legs into place as well. Press down again to ensure that each leg is firmly attached to the base.



③ Attach Handle to Basket:

- Insert handle and snap into place.

④ Attach Tad Character to Basket:

- Insert Tad character, front facing the handle.
- Tad character will be permanently attached.

For additional help,
please visit our Consumer Support website at
<http://www.leapfrog.com/support>
or write to:
LeapFrog Enterprises, Inc.
Attn: Consumer Services
8201 Hollis Street, Suite 153
Emeryville, CA 94600
Telephone: (800) 761-LEAP(5327)

LEAP FROG and the LEAP FROG LOGO
are registered trademarks of LeapFrog Enterprises, Inc.
PRETEND & LEARN is a trademark of
LeapFrog Enterprises, Inc.

© 2002 LeapFrog Enterprises, Inc. All rights reserved.

Pat No. 6,410,019E Art. Trad. No. 619-03350

Note: The Pretend & Learn™ Shopping Cart
is not intended to be a ride-on toy.