

Parent Guide & Instructions

This guide contains important information.
Please keep it for future reference.



Fun & Learn™ Sing Along Microphone™

Fun learning songs teach the ABCs, counting, and more!

Dear Parent,

We at LeapFrog® know that you are your child's most important teacher. Our goal is to help you build an environment for your youngster that is rich in experiences—one that will help your child to grow and develop.

Our Fun & Learn™ line teaches preschool fundamentals that help prepare children to enter the classroom. Cheerful characters and delightful songs enhance the play experience while teaching the alphabet, phonics, vocabulary, colors, numbers, and counting.

LeapFrog learning toys are designed to grow alongside your child through each stage of development, from the toddler period through the grade school years. All are made with the same playful spirit that promotes a life long love of learning. For additional information on how to make learning fun and effective, visit our web site www.leapfrog.com, where you'll find tips from parents and educators. We hope you'll join us there.

Sincerely,

Mike Wood

Mike Wood
President, LeapFrog

Battery Installation

1. Requires 3 AAA (called LRO3 in some countries) alkaline batteries.
2. When the batteries run low on power, the toy's speech may become garbled or it may repeat itself. Replace the batteries at this time.
3. Open the battery door with a screwdriver.
4. Install new batteries as shown in the polarity diagram (+/-) inside the battery compartment.
5. Replace battery door securely.

TROUBLE-SHOOTING

Symptom:

Try This:

Toy does not turn on or does not respond	<ul style="list-style-type: none">● Remove batteries and put them back in● Make sure battery cover is correctly secured● Clean battery contacts with rubbing alcohol● Install new batteries
Toy makes strange sounds or behaves erratically	<ul style="list-style-type: none">● Install new batteries
Toy makes improper responses	<ul style="list-style-type: none">● Check batteries

Consumer Service contact:

For additional help, please visit our Consumer Support Web site at: <http://www.leapfrog.com/support>

email: support@leapfrog.com

Telephone: (800) 701-LEAP (5327)

Hours: Monday through Friday, 9:00 AM to 5:00 PM, Pacific Time

IMPORTANT: Please notify the LeapFrog Consumer Service department of any difficulties before returning this product for any reason. Returns must have a Return Authorization number (RA#) in order to be processed. If the service representative is unable to solve the problem, you will be given instructions on how to replace the product.

Warranty Information:

This device complies with Part 15 of the FCC rules.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. Because this toy generates, uses, and can radiate radio frequency energy, there can be no guarantee that interference will not occur. If this toy does cause interference to radio or television reception (you can check this by turning the toy off and on while listening for the interference), one or more of the following measures may be useful:

- Reorient or relocate the receiving antenna.
- Increase the separation between the toy and the radio or the TV.
- Consult the dealer or an experienced TV-radio technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

LeapFrog® Warranty

This LeapFrog product is warranted only to the original purchaser for a period of three months from the original purchase date, under normal use and service, against defective workmanship and material. This warranty is void if the product has been damaged by accident or unreasonable use, immersion in water, neglect, abuse, battery leakage or improper installation, improper service, or other causes not arising out of defects in workmanship or materials. Repair or replacement as provided under this warranty is the exclusive remedy of the purchaser. LeapFrog shall not be liable for any incidental or consequential damages for breach of any express warranty on this product. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited to the duration of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

During the warranty period, your product will either be repaired or replaced at LeapFrog's option, when returned, shipping prepaid and with proof of purchase date as instructed by a LeapFrog service representative. In the event that your product is replaced, the replacement will be covered under the original warranty or for 30 days, whichever is longer.

LEAPFROG is a registered trademark of Knowledge Kids Enterprises, Inc. FUN & LEARN, SING ALONG MICROPHONE, and LEAP INTO LEARNING are trademarks of Knowledge Kids Enterprises, Inc. ©2000 Knowledge Kids Enterprises, Inc. All rights reserved. Patent pending.

MADE IN CHINA

Visit our fun-filled web site at: www.leapfrog.com

Demonstration batteries included.

For ages 2 years and up.

More fun learning toys from LeapFrog®!

Preschool



Fun & Learn™
Read & Sing Little Leap™



Fun & Learn™ Flying Friends™

Leap into Reading!™



LeapPad™



Phonics Writing Desk™

Leap into Learning™!

Help your child develop a love of learning that will last a lifetime:

It's all about having fun.

The best thing you can do to help your child learn is to make the experience fun and rewarding. We've added a heaping dose of fun to all of our learning products, with engaging characters, favorite songs, bright colors, and creative play patterns designed to delight your child while they teach fundamental skills.

Select products appropriate to your child's learning level.

Check package age-grading and product features to determine which toy is most appropriate for your child's learning level. To encourage a positive learning experience, try to select products that will challenge, without overwhelming your child.

Applaud your child's accomplishments.

Our talking toys provide positive feedback to reinforce correct responses. But nothing solidifies learning more than a parent's praise. Whenever possible, play alongside your child, applauding his efforts. Your enthusiasm will catch on, instilling in your child a love of learning that will last a lifetime.



HOW IT WORKS:

Sing along to learn the alphabet, counting, and more!

- Twist the Music Ring to select one of four songs.
- Press the Music Button to hear your selected song. Listen along to learn the words.
- Press and hold the Record Button and sing along to record your own voice.
- Press the Playback Button to hear your recording.

Create Your Own Song!

- Twist the Music Ring to the child symbol to create your own original song.
- Press and hold the Record Button while you sing.
- Press the Playback Button to hear your song played back.



Volume Control

- For quiet play, slide the Volume Switch from high to low.

Automatic Shutoff Feature

This toy turns off automatically if left unattended.

Instructions for Care:

- Keep product away from food and beverages.
- Clean with slightly damp cloth.
- **NEVER SUBMERGE TOY IN WATER.**
- Remove batteries during prolonged storage.
- Avoid extreme temperatures.

BATTERY INFORMATION

Batteries included are for in-store demonstration purposes only. Replace with new batteries to improve performance.

Battery Safety:

- Batteries are small objects. Replacement of batteries must be done by adults.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the toy.
- Dispose of used batteries properly.
- DO NOT incinerate used batteries.
- DO NOT mix old and new batteries or types of batteries (i.e. alkaline/standard).
- DO NOT use rechargeable batteries.
- DO NOT recharge non-rechargeable batteries.
- DO NOT short-circuit the supply terminals.